

Installation Instructions

There is a couple of different ways to use this mount. Please read the entire installation instructions before you start to make sure you are using the proper method for your hull.



Step 1 ↑

Mount bar in desired location. When mounting in a Mono or a hull with taller rails make sure it is mounted high enough to allow for the expanded bag but not too high that the bag can flop around. Filling the bag with air will help you find the height for mounting the bar. When mounting on short rails (cat's & hydro's) make sure you mount the bar as high as possible. See steps 7-9 for short rails.



Step 2 ↑

Place the back between the two washers and attach the fuel bag to wire as shown.



Step 3 ↑

Place the bag so that the outlets are behind the bar and mark the wires where they need to be cut as shown. Add 3/4's of an inch to this mark when mounting in short rails.



Step 4 ↑

Place one side in bar so that the wire is flush with the back of the bar and tighten the pinch bolt.



Step 5 ↑

Bend the wire until the bag mounting end is centered as shown.

Step 6

Remove the wire and repeat steps 4 and 5 for the other side.

NOTE: Steps 7, 8 & 9 are for short rails.



Step 7 ↑

Loosen the 1/4 inch bolts, rotate the bar so that the wire is aimed upwards as pictured and tighten the bolts back down.



Step 8 ↑

Mark and bend wire where needed to allow for expanded bag.



Step 9 ↑
This is the way it should look for short rails.



Step 10 ↑
Attach the bag as shown in step 2. Insert the wires into the bar and tighten the pinch bolts to complete the installation.

VenomCCRacing.com Phone: (321) 231-2898