

WARPATH FURY

Quick Setup Guide



Key Setup Points

Your Warpath FURY Rigger is shipped with a few plastic shims (0.060") to get you in the "ballpark".

We recommend that you fine tune the setup with additional shims as required. A shim kit such as this one from McMaster-Carr part # 97235K808 is very handy for this, or use shim stock.

Here is a good starting point setup:

- ▶ Tub level to setup table with rears on table
- ▶ Port sponson approx. AOA of 4.0 deg
- ▶ Starboard sponson approx. AOA of 4.5 deg
- ▶ Strut flat on setup table level with the rear sponsons (SM #SPDS-010-250MR or similar)
- ▶ FULL LENGTH straight rudder (SM #SPDR-013-1SB or similar)

- ▶ Ti-Titanium fin set with bottom edge level with the ride surface (setup table). NOTE: slight adjustments will be VERY noticeable.
- ▶ Port sponson parallel with the tub or 1/16 Toe-IN
- ▶ Starboard (turn fin) sponson Toe-IN 1/16"
- ▶ **DO NOT OVERTIGHTEN BOOM BOLTS!**
- * waterline in RB is steel, recommend flushing with WD40 or similar especially if boat will be sitting a while between uses.

We recommend the following props with the Warpath Fury:

- ▶ **7217/2 450 or 460 for smallblocks**
- ▶ **7217/2 480 or more for bigblocks**

Contact Brent Daily for the best prop for your Warpath. www.thepropworkswest.com